



G V O R

GVOR HEATED VEST

User Manual

Activate your 1 Year Limited Warranty



support@gvorheated.com




www.gvorheated.com



X1



X1



X1




X1

WHAT'S INCLUDED



Read all safety warnings and all instructions, including those given in accompanying brochure. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury. Save all warnings and instructions for future reference.

OPERATING INSTRUCTIONS



Insert the battery, clothing on the switch red - blue - green together with light 2S;

To turn on press and hold the power button on your apparel (located on the right side of the chest) for 3 seconds.

Heating zones will be activated, The apparel will begin to preheat for 5 minutes (blinking red LED light). Then it will automatically adjust to medium heat (blue LED light).

Auto shutdown 12 hours after the battery starts to power up, press the clothing switch to wake up to power up automatically.

To turn off, press and hold the power button for 3 seconds until LEDs turn off.

HEAT SETTING INDICATOR



PRE-HEAT
RED LED BLINKING



HIGH
RED LED



MEDIUM
WHITE LED



LOW
BLUE LED

The heating level can be adjusted by pressing the power button. Each press will cycle through the vest's temperature settings. At a room temperature of 69.8°F/21 °C, the heat will rise to 140°F/ 60°C on high, 131 °F/55°C on medium, and 113°F/45°C on low.

CLEANING INSTRUCTIONS



IMPORTANT:

DISCONNECT AND REMOVE the batteries from the pockets, put the connectors back, and put the vest in a mesh laundry bag for machine wash.



HAND WASH WITH COLD WATER
MACHINE WASH IN LAUNDRY BAG
GENTLE CYCLE IN COLD WATER
DO NOT IRON
DO NOT BLEACH
DO NOT DRY CLEAN
DO NOT WRING OR TWIST
LINE DRY

INFORMATION & WARNINGS

- Allow the product to dry completely before wearing if the inner lining becomes wet. Water entering a heated garment will increase the risk of electric shock.
- Disconnect the battery from the power cable and remove the battery pack before storing or hand washing the product. Such preventive safety measures reduce the risk of the product starting accidentally.
- Use the product in accordance with these instructions, taking into account the environment the product is to be worn. Use of the product for operations different from those intended could result in a hazardous situation.
- Continue to use high level for 20 minutes If there is any discomfort please immediately off the power.
- Consult your physician to determine if using this product is appropriate. Some medical conditions, medical devices or medications can cause sensitivity to heat.
- Shut off power immediately if any discomfort occurs.
- Discontinue use immediately If the product does not operate properly.
- Follow instructions given on the washing label or in the CLEANING INSTRUCTIONS section of this manual.

HEATED SOCKS SAFETY

INFORMATION & WARNINGS

- Maintain labels that carry important information. If it is unreadable or missing, email GVOR customer service at support@gvorheated.com

NEVER

- Use the product on
 - o An infant or young child
 - o An incapacitated or immobile person
 - o A person with diabetes
 - o A person who is paralyzed or has skin that is sensitive to temperature changes
 - o Anyone insensitive to heat, such as a person with poor blood circulation
 - o Anyone who cannot clearly understand the instructions and/or operate controls
- Use the product if the power button does not turn it on and off. Use the product when sleeping.
- Use the product under the influence of drugs or alcohol as this can increase skin sensitivity and/or impair the ability to recognize the sensation of a burn.
- Use the product on open wounds.
- Use the product continuously for over 2 hours. Check your feet/hand regularly or redness of the skin. Excessive heat levels over prolonged periods of time can lead to burns.
- Wait until your hands/feet are cold before increasing the heat setting. Cold hands/feet reduce the skin's sensation to heat and therefore increase the risk of burns.

BATTERY SAFETY & CHARGING INSTRUCTIONS

Rechargeable lithium-ion batteries are potentially hazardous and can present a serious FIRE HAZARD if damaged, defective, or improperly used. Before using the battery and charger, read the safety instructions below.

Fire hazard

Never attempt to open the battery pack for any reason. If the battery pack case is cracked or damaged, do not insert it into the charger. Do not crush, drop or damage the battery pack. Do not use a battery pack or charger that has received a sharp blow, been dropped, run over or damaged in any way (e.g., pierced with a nail, hit with a hammer, stepped on).

Fire hazard

Do not store or carry the battery pack so that metal objects can contact exposed battery terminals. For example, do not place the battery pack in aprons, pockets, tool boxes, product kit boxes, drawers, etc., with loose nails, screws, keys, etc. When transporting individual battery packs, make sure that the battery terminals are protected and well insulated from materials that could contact them and cause a short circuit.

Burn hazard

Battery liquid may be flammable if exposed to spark or flame.

BATTERY SAFETY & CHARGING INSTRUCTIONS

SPECIFICATIONS

Capacity	15000mAh/11.1V
Input	DC5V/3A
Size	70x102x26mm
Weight	9.23oz (270gram)

ALWAYS

- Fully charge before first use.
- Fully charge every 6 months.
- Charge the battery at recommended temperature of 41 °F to 104°F (5°C to 40°C)
- Use the battery at recommended temperature of 14T to 86 °F (-10°C to 30°C)
- Keep the battery away from moisture. Store the battery pack where the relative humidity is 60± 15% RH.



Risk of Fire and Burns. Do Not Open, Crush, Heat Above (113°F/45°C) or Incinerate Follow Manufacturer's Instructions. Prevent exposure of fire or heat source.

BATTERY SAFETY & CHARGING INSTRUCTIONS

NEVER

- Charge or use the battery in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Inserting or removing the battery from the charger may ignite the dust or fumes.
- Force the battery pack into the charger.
- Disassembles, drops, or break opens the battery pack or charger.
- Modify the battery pack in any way to fit into a non-compatible charger, as the battery pack may rupture, causing serious personal injury.
- Splash or immerse in water or other liquids.
- Store or use the battery pack in locations where the temperature may reach or exceed 105 °F (40 °C).
- Store or leave the product unattended with a battery connected.
- Store the battery pack together with metal objects.
- Dispose of used batteries in household trash or by burning.
- Incinerate the battery pack, even if it is severely damaged or is completely worn out. The battery pack can explode in a fire. Toxic fumes and materials are created when lithium-ion battery packs are burned.

Battery acid may leak from damaged batteries under abusive conditions. Avoid contact. In case of contact with battery acid, wash it off immediately with soap and water. In case of eye contact, rinse thoroughly for at least 10 minutes and immediately seek medical attention .

WARRANTY

GVOR's limited warranty applies to all BRAND-NEW items sold by gvorheated.com and other authorized dealers.

ONE (1) YEAR limited warranty covers any defects and malfunctions of this product from the date of purchase.

This warranty is non-transferable and proof of original purchase from us or an authorized dealer is required for warranty service.

Damage to the parts resulting from accidental fire, flood, misuse, unauthorized service, or negligence as outlined herein will void the warranty. The Warranty does not cover commercial use.

www.gvorheated.com